



# "W900 KENWORTH AEROCAB STANDARD VISOR (WITH CURVED WINDSHIELD)



## INSTRUCTIONS

1. UNPACK THE CARTON AND DETERMINE THAT YOU HAVE RECEIVED ALL OF THE PARTS REQUIRED FOR THIS INSTALLATION (SEE REVERSE SIDE OF THIS PAGE).
2. REMOVE THE OLD SUN VISOR FROM THE TRUCK AND SCREW THE FOUR BOLTS FROM THE ENDS OF THE VISOR BACK INTO THEIR RESPECTIVE POSITIONS AS WE WILL BE RE-USING THEM TO INSTALL THE NEW VISOR.
3. YOU MUST EXERCISE THE UTMOST IN CARE AND CAUTION FOR THE REST OF THIS INSTALLATION AS THE VISOR SECTIONS WILL NO LONGER HAVE THE PROTECTIVE COATING ON THEM. PLACE AN OLD RUG, A FEW RAGS OR SOME OTHER MEANS UNDER THE VISORS TO PROTECT THEM WHILE COMPLETING THIS INSTALLATION.
4. PEEL THE P.V.C. PROTECTIVE COATING FROM AND THEN MOUNT THE OUTSIDE BRACKET ON EACH OF THE VISOR SECTIONS UTILIZING THE TWO HOLES AT THE BOTTOM OF THE VISOR. (SEE CUT-AWAY VIEW) LEAVE ALL OF THE BOLTS IN A "FINGERTIGHT" CONDITION UNTIL THIS INSTALLATION HAS BEEN COMPLETED.
5. PLACE THE RIGHT (PASSENGER) SIDE OF THE VISOR IN POSITION ON THE TRUCK AND INSTALL THE TWO BOLTS IN THE END OF THE VISOR. THEN INSTALL THE TWO **METRIC** BOLTS THROUGH THE HOLES IN THE TOP OF THE VISOR, THROUGH THE BRACKET FURNISHED IN THE KIT AND ON INTO THE OUTSIDE MOUNT ON THE TRUCK ROOF.
6. REPEAT STEP #5 AND MOUNT THE LEFT (DRIVERS) SIDE OF THE VISOR.
7. SLIDE THE NEW CENTER BRACKET UNDER THE VISOR SECTIONS AT THE MIDDLE ROOF MOUNT AND VISUALLY LINE UP THE BOLT HOLES. PLACE THE BOLTS INTO THEIR RESPECTIVE POSITIONS. (**NOTE!** THE TOP FOUR BOLTS ARE **METRIC**).
8. CHECK THE COMPLETED SUN VISOR FOR PROPER ALIGNMENT AND TIGHTEN ALL OF THE BOLTS.
9. AFTER THE INSTALLATION IS COMPLETED AND DURING THE NORMAL OPERATION OF THE TRUCK, IT IS A GOOD IDEA TO CHECK THE VISOR BOLTS PERIODICALLY TO INSURE THAT THEY REMAIN TIGHT.



BY

